

NX-OS and Cisco Nexus Switching

Next-Generation Data Center Architectures

Second Edition

Ron Fuller, CCIE® No. 5851
David Jansen, CCIE® No. 5952
Matthew McPherson

ciscopress.com

NX-OS and Cisco Nexus Switching

Next-Generation Data Center Architectures

Second Edition

Ron Fuller, David Jansen,
Matthew McPherson

Cisco Press

800 East 96th Street

Indianapolis, IN 46240

NX-OS and Cisco Nexus Switching: Next-Generation Data Center Architectures

Table of Contents

Contents

Foreword

Introduction

Chapter 1 Introduction to Cisco NX-OS

- NX-OS Overview
  - NX-OS Supported Platforms
  - NX-OS Licensing
  - Nexus 7000
  - Nexus 5500
  - Nexus 3000
  - Nexus 2000
  - Nexus 1000v
  - Installing the NX-OS License File
  - Cisco NX-OS and Cisco IOS Comparison
- NX-OS User Modes
  - EXEC Command Mode
  - Global Configuration Command Mode
  - Interface Configuration Command Mode
- Management Interfaces
  - Controller Processor (Supervisor Module)
  - Connectivity Management Processor (CMP)
  - Telnet

Pearson

Table of Contents

SSH

SNMP

DCNM

Managing System Files

File Systems

Configuration Files: Configuration Rollback

Operating System Files

Virtual Device Contexts

VDC Configuration

VDC Interface Allocation

Interface Allocation: N7K-M132XP-12 and L

Interface Allocation: N7K-F132XP-15

Interface Allocation: N7K-M108X2-12L

Interface Allocation: 10/100/1000 Modules

Interface Allocation on M2 Modules

Troubleshooting

show Commands

debug Commands

Topology

Further Reading

Chapter 2 Layer 2 Support and Configurations

Layer 2 Overview

Store-and-Forward Switching

Cut-Through Switching

Fabric Extension via the Nexus 2000

Configuring Nexus 2000 Using Static Pinning

Nexus 2000 Static Pinning Verification

Configuring Nexus 2000 Using Port-Channels

Nexus 2000 Static Pinning Verification

Pearson

Table of Contents

- Layer 2 Forwarding on a Nexus 7000
- L2 Forwarding Verification

VLANs

- Configuring VLANs
- VLAN Trunking Protocol
- Assigning VLAN Membership
- Verifying VLAN Configuration

Private VLANs

- Configuring PVLANs
- Verifying PVLAN Configuration

Spanning Tree Protocol

- Rapid-PVST+ Configuration
- Verifying Spanning Tree State for a VLAN
- Spanning Tree Timers
- MST Configuration
- Additional Spanning Tree Configuration
- Port Cost
- Port Priority
- Spanning Tree Toolkit
- BPDUGuard
- BPDUFilter
- RootGuard
- LoopGuard
- Dispute Mechanism
- Bridge Assurance
- Spanning Tree Port Types
- Virtualization Hosts
- Configuring Layer 2 Interfaces
- Trunk Ports
- Standard Host

Table of Contents

Link to Virtualization Host

Port-Profiles

Port-Channels

Assigning Physical Ports to a Port-Channel

Port-Channel Flow Control

Verifying Load Distribution Across a Port-Channel

Virtual Port-Channels

vPC Peer-Gateway

vPC Peer-Switch

ARP Synchronization

Unidirectional Link Detection

Cisco FabricPath

vPC+

Configuring vPC+

Summary

Chapter 3 Layer 3 Support and Configurations

EIGRP

EIGRP Operation

Configuring EIGRP

EIGRP Summarization

EIGRP Stub Routing

Securing EIGRP

EIGRP Redistribution

OSPF

OSPFv2 Configuration

OSPF Summarization

OSPF Stub Routing

Securing OSPF

OSPF Redistribution

Table of Contents

- OSPFv3 Configuration

IS-IS

- IS-IS Configuration

BGP

- BGP Configuration
- BGP Neighbors
- Securing BGP
- BGP Peer Templates
- Advertising BGP Networks
- Modifying BGP Routing Metrics
- Verifying BGP-Specific Configuration

First Hop Redundancy Protocols

- HSRP
- HSRP Configuration
- HSRP Priority and Preempt
- Verifying the HSRP Configuration
- Securing HSRP
- HSRP Secondary Support
- HSRP Support for IPv6
- VRRP
- VRRP Configuration
- VRRP Priority and Preempt
- Verifying VRRP Configuration
- Securing VRRP
- VRRP Secondary Support
- HSRP, VRRP, and vPC Interactions
- GLBP
- GLBP Configuration
- GLBP Priority and Preempt
- Verifying GLBP Configuration

Table of Contents

Securing GLBP

GLBP Secondary Support

Summary

Chapter 4 IP Multicast Configuration

Multicast Operation

Multicast Distribution Trees

Reverse Path Forwarding

Protocol Independent Multicast (PIM)

RPs

PIM Configuration on Nexus 7000 and Nexus 5500

Configuring Static RPs

Configuring BSRs

Configuring Auto-RP

Configuring Anycast-RP

Configuring SSM and Static RPF

IGMP Operation

IGMP Configuration on Nexus 7000

IGMP Configuration on Nexus 5000

IGMP Configuration on Nexus 1000V

MSDP Configuration on Nexus 7000

Administrative Scoping of Multicast RPs in PIM

Configuring PIM Join and Prune Policies

Multicast and Control Plane Policing (CoPP)

Summary

Chapter 5 Security

Configuring RADIUS

RADIUS Configuration Distribution

Configuring TACACS+

Table of Contents

- Enabling TACACS+
- TACACS+ Configuration Distribution
- Configuring the Global TACACS+ Keys
- Configuring the TACACS+ Server Hosts
- Configuring TACACS+ Server Groups
- Configuring TACACS+ Source Interface

Configuring SSH

Cisco TrustSec

- Configuring AAA for Cisco TrustSec
- Defining Network Device Admission Control
- Configuring the Nexus 7000 for 802.1x and SGA Features
- SGT Assignment via ISE Server
- Policy Component: IP to SGT Mapping
- Policy Component: SGACL Creation

Configuring Cisco TrustSec: IEEE 802.1AE LinkSec

- Layer 2 Solutions Between Data Centers

Configuring IP ACLs

Configuring MAC ACLs

Configuring VLAN ACLs

Configuring Port Security

- Security Violations and Actions

Configuring DHCP Snooping

Configuring Dynamic ARP Inspection

- Dynamic ARP Inspection Trust State

Configuring IP Source Guard

Configuring Keychain Management

Configuring Traffic Storm Control

Configuring Unicast RPF

Configuring Control Plane Policing

Table of Contents

Configuring Rate Limits
SNMPv3
Summary
Chapter 6 High Availability
Physical Redundancy
Redundant Power Supplies
Redundant Cooling System
Redundant Supervisors
Redundant Ethernet Out-of-Band (EOBC)
Redundant Fabric Modules
Generic Online Diagnostics
Bootup Diagnostics
Runtime Diagnostics
On-Demand Diagnostics
NX-OS High-Availability Architecture
Process Modularity
Process Restart
Stateful Switchover
Nonstop Forwarding
In-Service Software Upgrades
Summary
Chapter 7 Embedded Serviceability Features
SPAN
SPAN on Nexus 7000
Configuring SPAN on Nexus 7000
SPAN on Nexus 5x00
Configuring SPAN on Nexus 5x00
SPAN on Nexus 1000V

Pearson

Table of Contents

Configuring SPAN on Nexus 1000V

ERSPAN on Nexus 1000V

ERSPAN on Nexus 7000

ERSPAN on Nexus 5x00

Embedded Analyzer

Smart Call Home

Smart Call Home Configuration

Configuration Checkpoint and Rollback on Nexus 7000

Checkpoint Creation and Rollback

Configuration Checkpoint and Rollback on Nexus 5x00

Checkpoint Creation and Rollback

NetFlow

Configuring NetFlow on Nexus 7000

Configuring NetFlow on Nexus 1000V

Network Time Protocol

Precision Time Protocol

IEEE 802.3az (Energy Efficient Ethernet)

Power On Auto-Provisioning

Python

Summary

Chapter 8 Unified Fabric

Unified Fabric Overview

Enabling Technologies

10-Gigabit Ethernet

Fibre Channel over Ethernet

Single-Hop Fibre Channel over Ethernet

Multhop Fibre Channel over Ethernet

Storage VDC on Nexus 7000

Pearson

Table of Contents

N-Port Virtualization

N-Port Identification Virtualization

FCoE NPV Mode

Nexus 5x00 Unified Fabric Configuration

Single-Hop FCoE Configuration: Nexus 5x00

FCoE-NPV on Nexus 5x00

Nexus 7000 Unified Fabric Configuration

Summary

Chapter 9 Nexus 1000V

Hypervisor and vSphere Introduction

Nexus 1000V System Overview

Nexus 1000V Switching Overview

Nexus 1000V VSM Installation

Nexus 1000V Deployed on Nexus 1010 Virtual Services Blade

Registering the Nexus 1000V Plug-In to VMware Virtual Center Management Application

Configuring the SVS Domain and Networking Characteristics

Connecting the Nexus 1000V VSM to the vCenter Server

Nexus 1000V Installation Management Center

VEM Installation Option on the Nexus 1000V Management Installation Center

vCenter Connection Option on the Nexus 1000V Management Installation Center

Creating the Uplink Profile

Adding the VEM to a ESX vSphere Host

Enabling the Telnet Server Process

Changing the VSM Hostname

Layer 3 Control

1000V Port Profiles

Pearson

Table of Contents

Virtual Network Management Center

Installing Virtual Network Management Center Software from OVA Downloaded from Cisco.com

Adding the VM-Manager for vCenter Connectivity in VNMC Management Application

Configuring the Cisco VNMC Policy-Agent on the 1000v VSM

Virtual Security Gateway

Install Virtual Security Gateway on the Nexus 1010

Configuring the Cisco VNMC Policy-Agent on the VSG

Verify That the VSG and VSM Are Registered Clients in VNMC

Creating a Tenant in VMMC

Virtual Extensible LAN

Deploying Virtual Extensible LAN

Nexus 1000v Network Analysis Module

Installing Nexus 1000v Network Analysis Module

Deploying the Nexus 1000v NAM as a Virtual Services Blade on the Nexus 1010

Summary

Chapter 10 Quality of Service (QoS)

QoS on Nexus 7000

Forwarding Architecture

Network-QoS Policies

Queuing Policies

QoS and Nexus 2000 Fabric Extenders

QoS and Nexus 7000 Virtual Device Contexts

QoS on Nexus 5x00

Forwarding Architecture

Network-QoS Policies

Queuing Policies

Pearson

Table of Contents

QoS and Nexus 2000 Fabric Extenders

QoS on Nexus 1000V

Forwarding Architecture

Classification in Nexus 1000V

Summary

Chapter 11 Overlay Transport Virtualization (OTV)

OTV Terminology and Concepts

OTV Control Plane

Multicast-Enabled Transport Infrastructure

Unicast-Enabled Transport Infrastructure

OTV Data-Plane

Data-Plane Multicast Traffic

OTV and QoS

Failure Isolation

STP Isolation

Unknown Unicast Handling with OTV

Broadcast Traffic Handling with OTV

Multihoming with OTV

OTV and ARP

First-Hop Routing Protocol Localization

Inbound Path Optimization

Summary

Chapter 12 Layer 3 Virtualization and Multiprotocol Label Switching (MPLS)

Virtual Routing and Forwarding

Predefined VRFs

VRF Operational Commands

VRF-Lite

Pearson

Table of Contents

MPLS Introduction

MPLS Terminology

LDP and Layer 3 VPNs

Quality of Service

Traffic Engineering

MPLS and IPv6: 6PE and 6VPE

Management and Troubleshooting

High Availability

Nexus Hardware Requirements and NX-OS Licensing for MPLS and VRF

Summary

Chapter 13 LISP

LISP Overview

LISP Terminology

LISP Prerequisites

LISP Control Plane

LISP Data Plane

Communicating Between LISP and non-LISP Sites

LISP Host Mobility with an Extended Subnet Mode

LISP Deployment Best Practices

Summary

Chapter 14 Nexus Migration Case Study

Existing Environment

Design Goals

The Design

Migration Plan

Premigration Steps

Table of Contents

- Maintenance Window #1
- Maintenance Window #1 Summary
- Maintenance Window #2
- Ongoing Maintenance Windows
- Summary

Index